

you can
Canon

INK
TONER

Consumables Compatibility Chart

2005-2006



PIXMA PRINTERS

| Machine | Product Type / Code | 40 Black PG40 | 41 Color CL41 | 50 Black PG50 | 51 Color CL51 | 52 Photo CL52 | 5 PGBK PG5 | 8 BK CL8BK | 8 C CL8C | 8 M CL8M | 8 Y CL8Y | 8 PC CL8PC | 8 PM CL8PM | 24 Black BCI-24 Black* | 24 Color BCI-24 Colour* | 15 Black BCI-15 Black** | 16 Color BCI-16 Colour** | 6 Black BCI-6 BK | 6 Cyan BCI-6 C | 6 Magenta BCI-6 M | 6 Yellow BCI-6 Y | 6 Photo BCI-6 PC | 6 Photo BCI-6 PM | 6 Red BCI-6 R | 6 Green BCI-6 G | 3e Black BCI-3e BK | | |
|--------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|------------------|------------------|----------------|----------------|----------------|------------------|------------------|------------------------------|-------------------------------|-------------------------------|--------------------------------|------------------------|----------------------|-------------------------|------------------------|------------------------|------------------------|---------------------|-----------------------|--------------------------|--|--|
| PIXMA iP8500 | 0615B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PIXMA iP6600D | 0617B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PIXMA iP6220D | 0616B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PIXMA iP6210D | 0618B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PIXMA iP6000D | 0619B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PIXMA iP5200 | 0628B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PIXMA iP5200R | 0620B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PIXMA iP5000 | 0621B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PIXMA iP4200 | 0622B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PIXMA iP4000/4000R | 0623B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PIXMA iP3000 | 0624B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PIXMA iP2200 | 0625B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PIXMA iP2000 | 0626B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PIXMA iP1600 | 0627B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PIXMA iP1000/1500 | 0628B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PIXMA iP90 | 0629B001 | | | | | | | | | | | | | | | | | | | | | | | | | | | |

*Also available as a Twin Pack
**Twin Pack

SELPHY & COMPACT PHOTO PRINTERS

| Machine | Product Type / Code | KP-361P (10x15 cm) 7737A001 | KP-721P (10x15 cm) 0807B001 | KP-1081P (10x15 cm) 9585A001 | KW-241P (10x20 cm) 9401A001 | KC-361P (5x9 cm) 7739A001 | KC-181F (5x9 cm) 7741A001 | KC-181L (17.3x22 mm) 7740A001 | BCI-16 Colour** 9818A002 |
|--------------|---------------------|--------------------------------|--------------------------------|---------------------------------|--------------------------------|------------------------------|------------------------------|----------------------------------|-----------------------------|
| SELPHY CP710 | | | | | | | | | |
| SELPHY CP510 | | | | | | | | | |
| SELPHY CP600 | | | | | | | | | |
| SELPHY CP400 | | | | | | | | | |
| SELPHY CP500 | | | | | | | | | |
| SELPHY CP330 | | | | | | | | | |
| SELPHY DS700 | | | | | | | | | |
| SELPHY DS810 | | | | | | | | | |
| CP-300 | | | | | | | | | |
| CP-220 | | | | | | | | | |
| CP-200 | | | | | | | | | |
| CP-100 | | | | | | | | | |

*Requires optional paper cassette for anything other than postcard size / **Twin Pack

PIXMA PRINTERS / SELPHY & COMPACT PHOTO PRINTERS

you can
Canon

PIXMA MULTIFUNCTIONALS

| | 40 Black PG40 | 41 Color CL41 | 50 Black PG50 | 51 Color CL51 | 5 PGBK | 8 BK | 8 C | 8 M | 8 Y | 24 Black BCI-24 BK | 24 Color BCI-24 C | 6 Black BCI-6 BK | 6 Cyan BCI-6 C | 6 Magenta BCI-6 M | 6 Yellow BCI-6 Y | 3e Black BCI-3e BK | |
|-------------|----------------------------|----------------------------|----------------------------|------------------------------|------------------------------|---------------------|---------------------|--------------------|--------------------|---------------------------------|--------------------------------------|---------------------------------------|-----------------------------|--------------------------------|-------------------------------|---------------------------------|----------------------|
| Machine | Product Type / Code | PG-40 0615B001 | CL-41 0617B001 | PG-50 High Yield 0616B001 | CL-51 High Yield 0618B001 | PGI-5BK 0628B001 | CLI-8BK 0620B001 | CLI-8C 0621B001 | CLI-8M 0622B001 | CLI-8Y 0623B001 | BCI-24 Black* 6881A002 / 6881A009 | BCI-24 Colour* 6882A002 / 6882A009 | BCI-6 BK 4705A002 | BCI-6 C 4706A002 | BCI-6 M 4707A002 | BCI-6 Y 4708A002 | BCI-3eBK 4479A002 |
| PIXMA MP800 | | | | | | | | | | | | | | | | | |
| PIXMA MP780 | | | | | | | | | | | | | | | | | |
| PIXMA MP760 | | | | | | | | | | | | | | | | | |
| PIXMA MP750 | | | | | | | | | | | | | | | | | |
| PIXMA MP500 | | | | | | | | | | | | | | | | | |
| PIXMA MP450 | | | | | | | | | | | | | | | | | |
| PIXMA MP170 | | | | | | | | | | | | | | | | | |
| PIXMA MP150 | | | | | | | | | | | | | | | | | |
| PIXMA MP130 | | | | | | | | | | | | | | | | | |
| PIXMA MP110 | | | | | | | | | | | | | | | | | |

*Also available as a Twin Pack

BUBBLE JET MULTIFUNCTIONALS

| | 24 Black BCI-24 BK | 24 Color BCI-24 C | 3e Black BCI-3e BK | 3e Cyan BCI-3e C | 3e Magenta BCI-3e M | 3e Yellow BCI-3e Y | 3e Photo BCI-3e PBK | 3e Photo BCI-3e PC | 3e Photo BCI-3e PM | | | | |
|------------------------|---------------------------------|--------------------------------------|---------------------------------------|-------------------------------|----------------------------------|---------------------------------|----------------------------------|---------------------------------|---------------------------------|----------------------|------------------------|-----------------------|-----------------------|
| Machine | Product Type / Code | BCI-24 Black* 6881A002 / 6881A009 | BCI-24 Colour* 6882A002 / 6882A009 | BCI-3e 4608A002 | BCI-3e 4611A002 | BCI-3e Photo 4612A002 | BCI-3e BK 4479A002 | BCI-3e C 4480A002 | BCI-3e M 4481A002 | BCI-3e Y 4482A002 | BCI-3e PBK 4485A002 | BCI-3e PC 4483A002 | BCI-3e PM 4484A002 |
| MultiPass 10 | | | | | | | | | | | | | |
| MultiPass C20 | | | | | | | | | | | | | |
| MultiPass C30 | | | | | | | | | | | | | |
| MultiPass C50 | | | | | | | | | | | | | |
| MultiPass C70 | | | | | | | | | | | | | |
| MultiPass C75 | | | | | | | | | | | | | |
| MultiPass C80 | | | | | | | | | | | | | |
| MultiPass C100 | | | | | | | | | | | | | |
| SmartBase MPC190 | | | | | | | | | | | | | |
| SmartBase MPC200 Photo | | | | | | | | | | | | | |
| SmartBase MPC400 | | | | | | | | | | | | | |
| SmartBase MPC600F | | | | | | | | | | | | | |
| SmartBase MP360/MP360S | | | | | | | | | | | | | |
| SmartBase MP370 | | | | | | | | | | | | | |
| SmartBase MP390 | | | | | | | | | | | | | |
| SmartBase MP700 Photo | | | | | | | | | | | | | |
| SmartBase MP730 Photo | | | | | | | | | | | | | |

*Also available as a Twin Pack

you can
Canon

BJC-SERIES BUBBLE JET PRINTERS

| Machine | Product Type / Code | 3e Black | 3e Cyan | 3e Magenta | 3e Yellow | 3e Photo | 3e PhotoCyan | 3e PhotoMagenta | 6 Black | 6 Cyan | 6 Magenta | 6 Yellow | 6 PhotoCyan | 6 PhotoMagenta |
|---------------------------|---|----------|---------|------------|-----------|----------|--------------|-----------------|---------|--------|-----------|----------|-------------|----------------|
| Bubble Jet BJC-3000 | BCI-10* Ink Tank / 0956A002 | | | | | | | | | | | | | |
| Bubble Jet BJC-50 | BCI-11 Black* Ink Tank / 0957A002 | | | | | | | | | | | | | |
| Bubble Jet BJC-55 | BCI-11 Colour* Ink Tank / 0958A002 | | | | | | | | | | | | | |
| Bubble Jet BJC-6000 | BCI-12 Photo Black* Ink Tank / 0959A002 | | | | | | | | | | | | | |
| Bubble Jet BJC-6100 | BCI-12 Photo Colour* Ink Tank / 0960A002 | | | | | | | | | | | | | |
| Bubble Jet BJC-6200 | BCI-3e Bk Ink Tank / 4479A002 | | | | | | | | | | | | | |
| Bubble Jet BJC-6200S | BCI-3e C Ink Tank / 4480A002 | | | | | | | | | | | | | |
| Bubble Jet BJC-6500 | BCI-3e M Ink Tank / 4481A002 | | | | | | | | | | | | | |
| Bubble Jet BJC-8200 Photo | BCI-3e Y Ink Tank / 4482A002 | | | | | | | | | | | | | |
| Bubble Jet BJC-85 | BCI-3e PBk Ink Tank / 4483A002 | | | | | | | | | | | | | |
| | BCI-3e PC Ink Tank / 4484A002 | | | | | | | | | | | | | |
| | BCI-3e PM Ink Tank / 4485A002 | | | | | | | | | | | | | |
| | BCI-6 Bk Ink Tank / 4705A002 | | | | | | | | | | | | | |
| | BCI-6 C Ink Tank / 4706A002 | | | | | | | | | | | | | |
| | BCI-6 M Ink Tank / 4707A002 | | | | | | | | | | | | | |
| | BCI-6 Y Ink Tank / 4708A002 | | | | | | | | | | | | | |
| | BCI-6 PC Ink Tank / 4709A002 | | | | | | | | | | | | | |
| | BCI-6 PM Ink Tank / 4710A002 | | | | | | | | | | | | | |
| | BC-10 Cartridge / 0905A002 | | | | | | | | | | | | | |
| | BC-11e Cartridge / 0907A002 | | | | | | | | | | | | | |
| | BC-30e Cartridge / 4608A002 | | | | | | | | | | | | | |
| | BC-31e Cartridge / 4609A002 | | | | | | | | | | | | | |
| | BC-32e Photo Cartridge / 4610A002 | | | | | | | | | | | | | |
| | BC-33e Cartridge / 4611A002 | | | | | | | | | | | | | |
| | BC-34e Photo Cartridge / 4612A002 | | | | | | | | | | | | | |
| | BC-50 Print Head / 0937A002 | | | | | | | | | | | | | |

*Contains 3 Ink Tanks

BUBBLE JET FAX

| Machine | Product Type / Code | BX-2 | BX-3 | BX-20 | BC-01 | BC-21e | BC-22e Photo | BCI-21 Black | BCI-21 Colour |
|-----------|---------------------|------|------|-------|-------|--------|--------------|--------------|---------------|
| FAX-B100 | 0882A002 | | | | | | | | |
| FAX-B110 | 0884A002 | | | | | | | | |
| FAX-B115 | | | | | | | | | |
| FAX-B120 | | | | | | | | | |
| FAX-B140 | | | | | | | | | |
| FAX-B150 | | | | | | | | | |
| FAX-B155 | | | | | | | | | |
| FAX-B160 | | | | | | | | | |
| FAX-B180C | | | | | | | | | |
| FAX-B190 | | | | | | | | | |
| FAX-B200 | | | | | | | | | |
| FAX-B210C | | | | | | | | | |
| FAX-B215C | | | | | | | | | |
| FAX-B220 | | | | | | | | | |
| FAX-B230C | | | | | | | | | |
| FAX-B320 | | | | | | | | | |
| FAX-B340 | | | | | | | | | |
| FAX-B360 | | | | | | | | | |
| FAX-EB10 | | | | | | | | | |
| FAX-EB15 | | | | | | | | | |

you can
Canon

LASER PRINTERS / LASER MULTIFUNCTIONALS

| Machine | Product Type / Code | EP-A 1548A003 | EP-E 1538A003 | EP-L 1526A003 | EP-P 1529A003 | EP-S 1524A003/6 | EP-W 1545A003 | EP-22 1550A003 | EP-25 5773A004 | EP-32 1561A003 | EP-52 3839A003 | EP-65 6751A003 | EP-72 3845A003 | EP-27 8489A002 | Cartridge 706 0264B002 | Cartridge 703 7616A005 |
|---------------------|---------------------|---------------|---------------|---------------|---------------|-----------------|---------------|----------------|----------------|----------------|----------------|----------------|----------------|----------------|------------------------|------------------------|
| LBP-4/4 Lite/4 Plus | | | | | | | | | | | | | | | | |
| LBP-4i/4U | | | | | | | | | | | | | | | | |
| LBP-8II/8III series | | | | | | | | | | | | | | | | |
| LBP-8IV | | | | | | | | | | | | | | | | |
| LBP-430W | | | | | | | | | | | | | | | | |
| LBP-460 | | | | | | | | | | | | | | | | |
| LBP-465 | | | | | | | | | | | | | | | | |
| LBP-660 series | | | | | | | | | | | | | | | | |
| LBP-800/810 | | | | | | | | | | | | | | | | |
| Laser Shot LBP-1120 | | | | | | | | | | | | | | | | |
| Laser Shot LBP-1210 | | | | | | | | | | | | | | | | |
| LBP-1000 | | | | | | | | | | | | | | | | |
| LBP-1260 series | | | | | | | | | | | | | | | | |
| LBP-1760/LBP-1760e | | | | | | | | | | | | | | | | |
| LBP-2000 | | | | | | | | | | | | | | | | |
| LBP-2460 | | | | | | | | | | | | | | | | |
| LBP-3260 | | | | | | | | | | | | | | | | |
| LBP-3200 | | | | | | | | | | | | | | | | |
| LBP-3000 | | | | | | | | | | | | | | | | |
| LBP-2900 | | | | | | | | | | | | | | | | |
| LaserBase MF6580PL | | | | | | | | | | | | | | | | |
| LaserBase MF6560PL | | | | | | | | | | | | | | | | |
| LaserBase MF6540PL | | | | | | | | | | | | | | | | |
| LaserBase MF6550 | | | | | | | | | | | | | | | | |
| LaserBase MF6530 | | | | | | | | | | | | | | | | |
| LaserBase MF5770 | | | | | | | | | | | | | | | | |
| LaserBase MF5750 | | | | | | | | | | | | | | | | |
| LaserBase MF5730 | | | | | | | | | | | | | | | | |
| LaserBase MF5650 | | | | | | | | | | | | | | | | |
| LaserBase MF5630 | | | | | | | | | | | | | | | | |
| LaserBase MF3110 | | | | | | | | | | | | | | | | |

COLOUR LASER PRINTER

| Machine | Product Type / Code | Cartridge 701 Blk 8287A003 | Cartridge 701 Yel 9288A003 | Cartridge 701 Mag 9285A003 | Cartridge 701 Cya 9286A003 | Cartridge 701L Yel 9288A003 | Cartridge 701L Mag 9289A003 | Cartridge 701L Cya 9290A003 | Cartridge 701 Drum 9623A003 |
|----------|---------------------|----------------------------|----------------------------|----------------------------|----------------------------|-----------------------------|-----------------------------|-----------------------------|-----------------------------|
| LBP-5200 | | | | | | | | | |

LASER FAX

| Machine | Product Type / Code | FX1 1551A003 | FX2 1556A003 | FX3 1557A003 | FX4 1558A003 | FX6 71559A003 | FX7 7621A002 | Cartridge T 7833A002 | FX-10 0263B002 |
|-----------------------------------|---------------------|--------------|--------------|--------------|--------------|---------------|--------------|----------------------|----------------|
| FAX-L100/L120 | | | | | | | | | |
| FAX-L200/L240/L250/L260/L280/L290 | | | | | | | | | |
| FAX-L260i/L300/L350/L360 | | | | | | | | | |
| FAX-L220/L295 | | | | | | | | | |
| FAX-L380 | | | | | | | | | |
| FAX-L800/L900 | | | | | | | | | |
| FAX-L1000 | | | | | | | | | |
| FAX-L550 | | | | | | | | | |
| FAX-L600 | | | | | | | | | |
| FAX-L400 | | | | | | | | | |
| FAX-L700 series | | | | | | | | | |
| FAX-L2000/FAX-L2000IP | | | | | | | | | |
| FAX-L3300i | | | | | | | | | |
| MultiPass L60 | | | | | | | | | |
| MultiPass L90 | | | | | | | | | |

PERSONAL COPIERS

| Machine | Product Type / Code | A30 1474A003 | E16 1492A003* | PC-30 14487A003 | E30 14491A003 | Cartridge M 6812A002 | Cartridge T 7833A002 |
|--|---------------------|--------------|---------------|-----------------|---------------|----------------------|----------------------|
| FC1/FC2/FC3/FC3II/FC5/FC5II | | | | | | | |
| FC200/FC200S/FC204/FC204S/FC206/FC208/FC210/FC220/FC220S/FC100/FC108 | | | | | | | |
| FC224/FC224S/FC226/FC228/FC230/FC530/FC120/FC128 | | | | | | | |
| FC310/FC330/FC336 | | | | | | | |
| PC6/PC7/PC7RE | | | | | | | |
| PC10 | | | | | | | |
| PC11/PC12 | | | | | | | |
| PC14/PC15/PC20/PC22/PC25 | | | | | | | |
| PC740/PC750/PC760/PC770/PC780 | | | | | | | |
| PC860/PC880/PC890 | | | | | | | |
| PCD320/PDC340 | | | | | | | |
| PC1210D/PC1230D/PC1270D | | | | | | | |

* Not available in the UK

you can
Canon



you can
Canon

Canon Inc.
www.canon.com

Canon Europa N.V.
www.canon-europe.com



English Edition
© Canon Europa N.V., 2005 (0905)